

12-10 HULL/ENGINE HOOD

Rubber Parts

NOTE

○ *The rubber parts on the watercraft are fastened in place with various adhesives. To replace a rubber parts, use a cement in the following table, or an equivalent.*

⚠ WARNING

Read all warnings and cautions on any solvents and adhesives used. Many of these products are flammable, may be harmful to the skin and eyes, and may give off harmful vapors. Use these solvents and adhesives only in a well-ventilated area and never near an open flame.

For this Application:	Type
Trim Seals of Steering Frame Covers Engine Hood Gasket Storage Cover Gasket Deck Mats	Synthetic Rubber Adhesive P/N: 92104-3701
Detents Bumpers	Cyanoacrylate cement
Side Pads	Low-Temperature Cure Adhesive (Epoxy Type)

CAUTION

Be very careful that the part is positioned correctly when you apply the cement. It may be impossible to reposition the part.

⚠ WARNING

Do not get any cyanoacrylate cement in your eyes or on your skin. If you do get some in your eyes, do not try to wash it out. Contact a physician immediately! If you do get some on your fingers, do not touch any other part of your body; your fingers will stick to anything they touch. Allow the cement to cure and it will eventually wear off.

Rubber Parts Location

Trim Seals of Steering Frame Covers [A]

